


DIRECTIONS FOR SETTING COMBINATION LOCK



1. Remove red plastic tab gently, taking care to keep each wheel positioned at "0."
2. Slide the button (A) in the direction **opposite** of the arrow to release the latch on the lock.
3. Slide the button (A) in the direction of the arrow and hold until step 4 has been completed.
4. Set number wheels (B) to the desired combination.
5. Release the button (A). The combination has now been set.
6. To re-set the combination, complete steps 1 thru 5.

Common Sense Cases
PO BOX 3546
Chatsworth, CA 91313

Toll-Free Phone: 866-405-8811
International Callers: 818-718-1893
Fax: 818-718-6742